Magneti Marelli Dinoplex AEC 101 External Wiring V 1.2 info@dinoplex.org 12/2008, www.dinoplex.org

Dinoplex Wiring to Switch

- 1 B+ (12V from ignition/Coil B+ to Dinoplex B+)
- 2 K (to Coil -)
- 3 D (from distributor points / to tacho)
- 4 to Tacho (units from 1969-1970)

External Wiring

- 1 B+ (12V from ignition/Coil B+ to Dinoplex B+)
- 2 K (to Coil 'K')
- 3 A (to ballast resistor for 'Emergenza' mode)
- 4 D (from distributor points)

